

CREATE
YOUR STYLE

SWAROVSKI

Swarovski Create Your Style

Pre-Season FW
16/17
Mini Projects

Celebrating 120
Years of
Swarovski
Crystal





Happy Anniversary Golden Shadow Necklace

This triple strand necklace combines the ever so popular Swarovski Mini Beads with Swarovski's best-selling coating, Crystal Golden Shadow, to create an elegant, yet easy to make design.

Swarovski crystals:

Product Group	Article No.	Amount	Size	Color	Color Code
Mini Beads	5051	10 pcs	10x8mm	Crystal Golden Shadow	001 GSHA
Mini Beads	5052	20 pcs	8mm	Crystal Golden Shadow	001 GSHA
Mini Beads	5053	15 pcs	8mm	Crystal Golden Shadow	001 GSHA
Mini Beads	5054	15 pcs	8mm	Crystal Golden Shadow	001 GSHA
Mini Beads	5055	15 pcs	10x8mm	Crystal Golden Shadow	001 GSHA
Mini Beads	5056	10 pcs	12x8mm	Crystal Golden Shadow	001 GSHA
Crystal Pearls	5810	35 pcs	4mm	Vintage Gold	001 651

Supplies:

48" beading wire

6 2x2 crimp beads in gold or brass

6 3x3 crimp covers in gold or brass

1 lobster clasp in gold or brass

1 8mm Jump ring in gold or brass

12" Round Brass Cable Chain 10mm TierraCast® 20-0525-26

Tools: Round nose pliers, Flat nose pliers, Wire cutters

Happy Anniversary Golden Shadow Necklace – continued

Instructions:

- Step 1: Cut a 16" piece of beading wire. String one end of one wire through a crimp bead, through an end loop in the cable chain and back through the crimp bead. Crimp the bead to secure and cut off excess wire. Attach a crimp bead cover.
- Step 2: String on one Swarovski Crystal Pearl art. 5810 4mm, Vintage Gold. String 28 Swarovski Beads in a varying pattern adding a pearl after 2 or 3 beads. (Use 9 Swarovski Crystal Pearls on this strand; one at the beginning, one at the end and 7 in between the beads.) Crimp the other end of the wire to the opposite end of the cable chain as done for the other side.
- Step 3: Repeat steps 1 & 2 for the second strand.
- Step 4: Repeat steps 1 & 2 for the third strand using all the remaining beads and pearls.
- Step 5: Open the middle link in the cable chain and attach the 8mm jump ring and the lobster clasp.

Tip: You can even make one strand a few beads shorter and use the extra beads to make a matching pair of earrings! Lay the beads & pearls out on a bead board to see the pattern before stringing & crimping.



Mini Crystal AB Necklace

Swarovski mini beads in Crystal AB, the popular coating developed in collaboration with Christian Dior in 1956, give the metal spacer beads and black leather cord an elegant, yet edgy vibe.

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Mini Beads	5051	20 pcs	8x6mm	Crystal AB	001 AB
Mini Beads	5052	5 pcs	8mm	Crystal AB	001 AB
Mini Beads	5053	10 pcs	8mm	Crystal AB	001 AB

Supplies:

40" 1mm black leather cord

11 4x2 Deco Barrel TierraCast® 94-5803-12

Tools: Flat nose pliers, Wire cutters or scissors

Instructions:

Step 1: String the following beads onto the 1mm piece of leather. One 4x2 Deco Barrel, 1 Swarovski Bead art. 5051 8x6mm, 1 Swarovski Bead art. 5053 8mm, 1 Swarovski Bead art. 5051 8x6mm, 1 Swarovski Bead art. 5052 8mm, 1 Swarovski Bead art. 5051 8x6mm, 1 Swarovski Bead art. 5053 8mm, 1 Swarovski Bead art. 5051 8x6mm and one 4x2 Deco Barrel.

Step 2: Measure approximately 6" from the end of the leather cord and crimp the first Deco Barrel bead. Slide all of the other beads together and crimp the last Deco Barrel bead.

Mini Crystal AB Necklace - continued

- Step 3: Measure 3 inches down from the last Deco Barrel Bead and repeat step 1 and Step 2 four more times.
- Step 4: Use the last Deco Barrel bead to crimp the two cord ends together, making sure the cords are side by side and not overlapping each other. Also make sure that the beaded stations on both sides of the necklace are aligned. Trim excess cord from ends of Deco Barrel bead.

Tip: wrap this necklace around twice for a double strand necklace or wrap around your wrist for a trendy layered bracelet look!



Rue de Rivoli Necklace

Stunning and simple! Glue, connect and go! Make this sparkling necklace in a flash and wear it to your next anniversary party!

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Round Stone	1122	3 pcs	18mm	Crystal Vitrail Light	001 VL

Supplies:

- 30" 1mm black leather cord
- 4 4x2 Deco Barrel TierraCast® 94-5803-25
- 1 Twisted Hook Clasp TierraCast® 94-6199-25
- 3 18mm Faceted Rivoli link TierraCast® 94-3155-25
- 2 8mm jump rings
- Two part epoxy glue

Tools: Flat nose pliers, Round nose pliers, Wire cutters or scissors

Instructions:

- Step 1: Mix the two-party epoxy glue according to the instructions on the package. Place a small amount of glue in the center of Faceted Rivoli link. Press the Swarovski 18mm Round Stone, art. 1122 in the center of the link. Press the stone to secure in the link. Repeat for the other two Swarovski Round Stones and Rivoli links. Set aside and allow to dry as indicated in the glue instructions.
- Step 2: Open the two 8mm jump rings and connect the three links together.

Rue de Rivoli Necklace - continued

- Step 3: Cut the black leather cord in half. String one piece of cord through the loop at one end of the Rivoli link chain and bring the cord ends together evenly. Slide one Deco Barrel bead onto both cord ends and slide it down to about $\frac{1}{4}$ " from the loop in the link. Crimp the Deco Barrel bead to secure. Slide both cord ends through another Deco Barrel bead, through the loop at the bottom of the Twisted Hook Clasp and back through the Deco Barrel bead. Pull cord and Deco bead close to the loop in the clasp, crimp the Deco bead to secure and trim off excess cord.
- Step 4: Attach the other piece of leather cord to the other side of necklace as done in step 3, but form the cord endings to a loop and slide the ends into the Deco Barrel bead. Crimp the Deco Barrel bead to secure. This will form the loop for the Twisted Hook Clasp to secure the necklace.

Tip: Use a shorter piece of cord to create a matching bracelet. Use various colors and coatings of the Swarovski Round Stone art. 1122 to create this design to go with everything!

CREATE
YOUR STYLE

SWAROVSKI



Patina Rivoli Drops

The Swarovski Patina effects help you create vintage and estate style jewelry in a variety of hues. These Patina Rivoli Drops are made with Swarovski Round Stones & Beads in the Crystal Black Patina effect for an elegant and trendy look.

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Round Stones	1122	2 pcs	12mm	Crystal Black Patina	001 BLAPA
Round Stones	1122	2 pcs	14mm	Crystal Black Patina	001 BLAPA
Beads	5040	2 pcs	4mm	Jet	280
Beads	5040	2 pcs	8mm	Jet	280
Pendants	6010	6 pcs	13x6.5mm	Crystal Black Patina	001 BLAPA

Supplies:

- 2 Add a bead ear wires TierraCast® 90-1120-00
- 2 14mm Faceted Rivoli link TierraCast® 94-3153-61
- 2 12mm twisted round 1-3 Rivoli frame TierraCast® 94-3121-61
- 8 4mm jump rings
- 2" 20 gauge wire
- Two part epoxy

Tools: Flat nose pliers, Round nose pliers, Wire Cutters

Instructions:

Step 1: Mix the two-party epoxy glue according to the instructions on the package. Place a small amount of glue in the center of the 14mm Faceted Rivoli link. Press the Swarovski 14mm Round Stone, art. 1122 Crystal Black Patina in the center of the link. Press the stone to secure in the link. Repeat with the other 14mm Faceted link as well as the two 12mm Twisted Round 1-3 Rivoli frames using the Swarovski 12mm Round Stones. Set aside and allow to dry as indicated in the glue instructions.

Patina Rivoli Drops - continued

- Step 2: Attach one 4mm jump rings to four of the Swarovski Pendants art. 6010 Crystal Black Patina. Attach each one to the two end loops on the 12mm Twisted Round 1-3 Rivoli frames. Attach two 4mm jump rings to the remaining two Swarovski Pendants art. 6010 and attach these to the two middle loops of the 12mm Rivoli frame.
- Step 3: Turn a loop at the bottom of the 20 gauge wire. Slide the Swarovski Bead art. 5040 8mm Jet onto the wire and turn a loop at the other end. Repeat this step once. Attach one loop of one beaded wire to the top loop of the 12mm Rivoli frame and to one loop of the 14mm Faceted Rivoli link. Repeat for the other earring.
- Step 4: Attach the Swarovski Bead art. 5040 4mm Jet to the Add a Bead ear wire and attach the ear wire to the top loop of the 14mm Faceted link. Repeat for the other earring.

Tip: Use various colors and coatings of the Swarovski Round Stone art. 1122 to create these earrings to go with everything in your closet!



Infinity X Infinity Choker

The new Swarovski Infinity Pendant mixed with golden infinity links combine to create a classic necklace for all time.

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6792	12 pcs	18mm	Crystal Golden Shadow	001 GSHA

Supplies:

- 13 Infinity Links TierraCast® 94-3167-25
- 1 Large Classic Hook Clasp TierraCast® 94-6178-25
- 40 10mm jump rings

Tools: Flat nose pliers, Round nose pliers

Instructions:

- Step 1: Use two 10mm jump rings to connect each of the 13 Infinity Links together to form a chain. Add two 10mm jump rings to each end of the Infinity chain. On one end of the chain add the Classic Hook Clasp.
- Step 2: Attach one 10mm jump ring to one of the Swarovski Infinity Pendants, art. 6792 18mm. Attach this to the first loop in the fifth Infinity Link in the chain. Close the jump ring to secure.
- Step 3: Repeat step 2 and attach another Swarovski Infinity Pendant to the next loop in the fifth link in Infinity chain. Repeat until all remaining Swarovski Infinity Pendants are attached to the Infinity chain, attaching one to each consecutive loop.

Tip: You can increase the length of the choker by increments of 1 1/4" by adding one Infinity Link. You can also make this necklace with Swarovski Crystal Silver Night Infinity Pendants and silver infinity links to match the Triple Infinity Earrings.

CREATE
YOUR STYLE



Triple Infinity Earrings

The never ending Swarovski Infinity Pendants make for a fashion trend that will also last to infinity and beyond!

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6792	6 pcs	18mm	Crystal Silver Night	001 SINI

Supplies:

- 2 Infinity Links TierraCast® 94-3167-40
- 2 ear wires
- 4 10mm jump rings
- 4 8mm jump rings
- 32 6mm jump rings

Tools: Flat nose pliers, Round nose pliers

Instructions:

- Step 1: Attach an 8mm jump ring to the bottom loop of the ear wire. Make a chain of six, 6mm jump rings and attach to the 8mm jump ring. Make a chain of two, 6mm jump rings and also add to the 8mm jump rings. Make another chain of six, 6mm jump rings and add to the other side of the "two jump ring chain". (This short chain will be in between the two longer jump ring chains.
- Step 2: Open an 8mm jump ring and attach to the bottom link in the two jump ring chain and to the small loop of the Swarovski Infinity Pendant, art. 6792 18mm. Make sure all jump rings are closed securely.
- Step 3: Attach the two bottom links of the six jump ring chain to the two loops of the Infinity link.

Triple Infinity Earrings – continued

Step 4: Attach an 8mm jump ring to the smaller loop of the Swarovski Infinity Pendant, art. 6792 18mm and attach this to one of the loops in the bottom of the Infinity link. Repeat this step to attach another Swarovski Infinity Pendant to the loop on the other side of the Infinity link.

Step 5: Repeat steps 1-4 to make second earring.

Tip: You can also make this necklace with Swarovski Crystal Golden Shadow Infinity Pendants and gold infinity links to match the Infinity X Choker (on page???)

CREATE
YOUR STYLE



Showers of Edelweiss

The new Swarovski Edelweiss Pendants combine beautifully with the Swarovski Mini Beads to create a subtle, yet striking statement piece.

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6748/G	3 pcs	14mm	Crystal Blue Shade	001 BLSH
Pendants	6748	2 pcs	18mm	Crystal	001
Pendants	6748/G	1 pc	28mm	Crystal	001
Mini Beads	5052	14 pcs	6mm	Crystal	001
Mini Beads	5051	16 pcs	10x8mm	Crystal Blue Shade	001 BLSH

Showers of Edelweiss - continued

Supplies:

- 30" 20 gauge wire
- 6 8mm jump rings
- 1 10mm jump ring
- 14 4mm oval jump rings
- 1 Lobster claw
- 1 12 Hole End Bar TierraCast® 94-3171-40
- 7" brass cable chain 2x6mm TierraCast® 20-0925-12

Tools: Flat nose pliers, Round nose pliers, Cutters

Instructions:

- Step 1: Turn a loop at one end of the 20 gauge wire. Slide on one Swarovski Bead art. 5052 6mm Crystal beads and turn a loop at the top of the bead. Cut off excess wire. Repeat with the remaining 13 Swarovski Bead art. 5052 and the 16 Swarovski Bead art. 5051 10x8mm Crystal Blue Shade beads.
- Step 2: Create a 15 link beaded chain with the beaded eye pins made in Step 1. Alternate the Swarovski Bead art. 5051 and Swarovski Bead art. 5052, beginning and ending with the Swarovski bead art. 5051. Repeat this step once.
- Step 3: Attach both beaded chains to the top loop in the 12 Hole End Bar. Attach the lobster clasp to the end of one chain and one 8mm jump ring to the other chain end.
- Step 4: Cut the cable chain to these lengths: One ¼" (or two links), two ¾" (or 5 links), one 1 ¼" (or 8 links) and one 1 ¾" (or 11 links).
- Step 5: Attach one 8mm jump ring to each of the Swarovski Pendant art. 6748/G 14mm Crystal Blue Shade, 18mm Crystal and 28mm Crystal pendants. Attach one 6mm oval jump ring to the 8mm jump rings on each pendant.
- Step 5: Attach one 14mm pendant from step 5 to the ¼" chain. Attach another 6mm oval jump ring to the top of the chain and attach it to the first loop in the 12 Hole End bar. Repeat this step using one of the ¾" pieces of chain and attach to the third loop in the 12 Hole End Bar. Repeat once more with the 1 ¼" chain and attach to the 5th loop in the bar.
- Step 6: Repeat step 5 using the 18mm pendant and the other ¾" piece of chain and attach it to the next to the last loop in the bar.
- Step 7: Attach the other 18mm pendant to the 5th hole from the end of bar using one 6mm oval jump ring.
- Step 8: Attach one 6mm oval jump ring to each of the middle two loops in the bar (loops 6 & 7). Attach these together with another 6mm jump ring attached to the 1 ¾" chain. Attach the 28mm pendant to the bottom of this chain. Make sure all jump rings are closed securely.

Tip: You can make the overall length of the necklace 2" longer by adding one Swarovski Bead art. 5051 and 5052 to each side.

CREATE
YOUR STYLE



Showers of Edelweiss Earrings

These beautiful earrings can be worn alone or to compliment the Showers of Edelweiss Necklace.

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Pendants	6748	2 pcs	14mm	Crystal	001
Pendants	6748/G	2 pcs	18mm	Crystal Blue Shade	001 BLSH
Beads	5328	2 pcs	4mm	Crystal	001

Supplies:

- 4 8mm jump rings
- 8 4mm oval jump rings
- 2 3 Hole End Bar TierraCast® 94-3168-40
- 8" brass cable chain 2x6mm TierraCast® 20-0925-12
- 2 Add a bead ear wires TierraCast® 90-1120-00

Tools: Flat nose pliers, Round nose pliers, Cutters

Showers of Edelweiss Earrings – continued

Instructions:

- Step 1: Cut two 1 $\frac{3}{4}$ " pieces of chain and two $\frac{3}{4}$ " pieces of chain. Attach the 8mm jump rings to all of the Swarovski Pendants art. 6748 14mm and 6748/G 18mm. Attach a 6mm jump ring to all of the 8mm jump rings.
- Step 2: Attach one $\frac{3}{4}$ " piece of chain to the 6mm jump ring on one of the 18mm pendants. Attach a 6mm jump ring to the top of the chain and attach it to one of the outside loops of the 3 Hole End Bar. Repeat this step with the other 18mm pendant and other 3 Hole End Bar.
- Step 3: Attach one 1 $\frac{3}{4}$ " piece of chain to the 6mm jump ring on one of the 14mm pendants. Attach a 6mm jump ring to the top of the chain and attach it to the other outside loop of the 3 Hole End Bar. Repeat this step with the other 14mm pendant.
- Step 4: Slide the Swarovski Bead art. 5328 4mm Crystal onto the Add a Bead ear wire. Open the loop at the bottom of the ear wire and attach it to the top loop in the 3 hole end Bar. Repeat this step with the other ear wire.

Tip: Create a simple charm bracelet by simply attaching the Edelweiss pendants to a heavy linked chain with 6 & 9mm jump rings. Just cut the chain to your desired length and add a lobster clasp to one end.

CREATE
YOUR STYLE



Ring In Our Anniversary

These statement rings can be made with a variety of Swarovski Round Stones, Fancy Stones and Flat Back Stones.



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Fancy Stone	4753	1 pc	14m m	Crystal	001
Flat Back Stones	2753	1pc	14m m	Crystal AB	001 AB
Round Stones	1088	14 pcs	PP21	Crystal	001
Round Stones	1088	18 pcs	PP21	Crystal AB	001 AB
Round Stones	1088	6 pcs	PP28	Crystal AB	001 AB
Plastic trimming	50 004	3-4 inches	PP24	Crystal/White/Transparent	001/022/010
Ceralun® Epoxy Clay	9030/290	20 gr pkg	n/a	White	01

Supplies:

- 2 Adjustable size ring components
- Tweezers or wax stick
- Jacquard Powder Pigment Pearl Ex in Silver
- Jacquard Powder Pigment Pearl Ex in Gold
- Alcohol wipes
- Disposable gloves

Ring In Our Anniversary – continued

Instructions: Silver Anniversary Ring:

- Step 1: Wearing rubber gloves, mix about 2 grams of each component of the Ceralun® Epoxy Clay, per instructions on package. Form into a ball the size of the ring base and form a dome on top of the ring base. You can use more or less Ceralun® depending on the size of the dome you prefer.
- Step 2: Embellish the Ceralun® dome on the ring using tweezers or wax stick. Start pattern by placing the Swarovski Flat back Stone art. 2753 14mm Crystal AB in the center of the Ceralun®. Push far enough into clay to cover girdle of stone. Add rows of three Swarovski Round Stones, art. 1088 PP21 Crystal AB, down the sides of the Ceralun dome. Finish by adding one Swarovski Round Stone art. 1088 PP 28 Crystal AB in between each row of PP21 stones. Coat the Ceralun® with the silver powder pigment.
- Step 3: Use an alcohol wipe to clean any residue left behind on the stone. The stone might look clean, but this needs to be done before the Ceralun® dries so we recommend you wiping it even if it looks clean. Let cure undisturbed for 24 hours.

Instructions: Golden Anniversary Ring:

- Step 1: Wearing rubber gloves, mix about 2 grams of each component of the Ceralun® Epoxy Clay, per instructions on package. Form into a ball the size of the ring base and form a dome on top of the ring base. You can use more or less Ceralun® depending on the size of the dome you prefer.
- Step 2: Embellish the Ceralun® dome on the ring using tweezers or wax stick. Start pattern by placing the Swarovski Fancy Stone art. 4753 14mm Crystal in the center of the Ceralun®. Push far enough into clay to cover girdle of stone. Add the row of Swarovski Plastic Trimming art. 50 004 to the bottom of the dome. Add the Swarovski Round Stones, art. 1088 PP 21 just above the plastic trimming. . Coat the Ceralun® with the gold powder pigment.
- Step 3: Use an alcohol wipe to clean any residue left behind on the stone. The stone might look clean, but this needs to be done before the Ceralun® dries so we recommend you wiping it even if it looks clean. Let cure undisturbed for 24 hours.

Tip: Although it takes 24 hours for the Ceralun® to cure completely it will start to harden in about 45 minutes so be sure to only mix as much as you need for the project you are working on to avoid waste. Also, when using Flat Back Stones with Ceralun®, it is recommended to use only the larger Flat Back Stones so they do not get “lost” in the Ceralun®.

CREATE
YOUR STYLE

SWAROVSKI



Field of Edelweiss Compact

Create this beautiful compact for a one of a kind gift that is sure to please!

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Fancy Stone	4753	6 pc	14mm	Crystal	001
Fancy Stone	4753	1 pc	23mm	Crystal	001
Ceralun	9030/290	20 gr pkg	n/a	White	01
Round Stones	1088	100 pcs	PP21	Crystal	001

Supplies:

1 Compact
Tweezers or wax stick
Jacquard Powder Pigment Pearl Ex in rose
Disposable gloves
Alcohol wipes

Instructions:

- Step 1: Wearing rubber gloves, mix about 4 grams of each component of the Ceralun® Epoxy Clay, per instructions on package. Form into a ball the size of the compact and form a dome on top of the compact. You can use more or less Ceralun® depending on the size of the dome you prefer.
- Step 2: Embellish the Ceralun® dome using tweezers or wax stick. Start pattern by placing the Swarovski Fancy Stone art. 4753 23mm Crystal in the center of the Ceralun®. Push far enough into clay to cover girdle of stone. Add the Swarovski Fancy Stone art. 4753 14mm around the 23mm stone. Fill in with the Swarovski Round Stones, art. 1088 PP21 Crystal Chatons. Coat the Ceralun® with the rose powder.
- Step 3: Use an alcohol wipe to clean any residue left behind on the stone. The stone might look clean, but this needs to be done before the Ceralun® dries so we recommend you wiping it even if it looks clean. Let cure undisturbed for 24 hours.

Tip: Ceralun® Epoxy Clay will adhere to most anything and create a permanent bond. You can use it to embellish a variety of jewelry designs, home décor items and accessories along with Swarovski Chatons and Fancy Stones.

CREATE
YOUR STYLE

SWAROVSKI



Crystallized Edelweiss Flip Flops

Crystallize your flip flops for sparkling summertime fun whether you're dancing through the fields in Austria or just lounging by the pool!

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Flat Back Hotfix	2753	16 pcs	10mm	Crystal AB	001AB
Flat Back Hotfix	2038	14 pcs	SS5 or SS6	Crystal	001

Supplies:

Flip Flops
Two Part Epoxy Glue (5 minute)
Small plastic disposable cups for mixing glue
Toothpicks
Tweezers or wax stick

Instructions:

Step 1: Wearing rubber gloves, mix a small amount of glue in the plastic cup, per instructions on package. Using a toothpick, place a small drop of glue on the flip flop where you want to place the stones. Using the tweezers or wax stick pick up the Swarovski Crystal Flat Back Stones art. 2753 & 2038 and apply to the glue. Press the stone firmly in place. Do not use too much glue or the stone will slide off the flip flop band and the glue will show around the edge of the stone.

Step 2: Use an alcohol wipe to clean any residue left behind on the stones. The stone might look clean, but this needs to be done before the glue dries so we recommend you wiping it even if it looks clean. Let cure undisturbed for 24 hours.

Tip: The glue will dry fast so don't mix too much at once. You can also mix the glue on a sturdy piece of paper or cardboard if you don't have disposable plastic cups. Although the glue will start to dry within a few minutes, it takes 24 hours for the glue to cure completely.

CREATE
YOUR STYLE



Crystallized Edelweiss Cell Phone Case

Crystals add a flair of excitement to everything! Crystallize an ordinary cell phone or tablet case that will be sought after by all of your friends.

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Flat Back Hotfix	2753	5 pcs	10mm	White Opal	234
Flat Back Hotfix	2753	5 pcs	10mm	Crystal Silver Shade	001SSHA
Flat Back Hotfix	2753	4 pcs	14mm	Crystal	001

Supplies:

Cell phone or table case
Two Part Epoxy Glue (5 minute)
Small plastic disposable cups for mixing glue
Toothpicks
Tweezers or wax stick

Instructions:

Step 1: Wearing rubber gloves, mix a small amount of glue in the plastic cup, per instructions on package. Using a toothpick, place a small drop of glue on the case where you want to place the stone. Using the tweezers or wax stick pick up the Swarovski Crystal Flat Back Stones art. 2753 and apply to the glue. Arrange the stones in the desired pattern, pressing them firmly in place. Do not use too much glue or it will show around the edge of the stone.

Step 2: Use an alcohol wipe to clean any residue left behind on the stones. The stone might look clean, but this needs to be done before the glue dries so we recommend you wiping it even if it looks clean. Let cure undisturbed for 24 hours.

Tip: The glue will dry fast so don't mix too much at once. You can also mix the glue on a sturdy piece of paper or cardboard if you don't have disposable plastic cups. Although the glue will start to dry within a few minutes, it takes 24 hours for the glue to cure completely.