

CREATE
YOUR STYLE

SWAROVSKI

*Special Occasion & Bridal Jewelry
With crystals from Swarovski*



Everlasting Love

A classic pearl necklace that is a must for everyone's jewelry box. Create this classic necklace in a variety of Swarovski crystal pearl colors to go with every outfit in your closet!



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearl	5810	2 pcs	4mm	Crystal White	001 650
Crystal Pearl	5810	2 pcs	5mm	Crystal White	001 650
Crystal Pearl	5810	2 pcs	6mm	Crystal White	001 650
Crystal Pearl	5810	6 pcs	8mm	Crystal White	001 650
Crystal Pearl	5810	10 pcs	10mm	Crystal White	001 650
Crystal Pearl	5810	10 pcs	12mm	Crystal White	001 650
Crystal Pearl	5810	5 pcs	14mm	Crystal White	001 650
Xilion Square Rondelle or Rondelle Spacer	77806 or 77506	32 pcs	6mm	Crystal/Rhodium	001 H

Supplies:

- 1 Tierracast 94-6217-12 Claddagh Clasp Set (or similar clasp)
- 2 silver crimp beads
- 2 silver crimp bead covers
- 27" 49 strand beading wire

Tools: Wire cutters, crimping pliers

Skill Level: Beginner

Techniques: Basic stringing & crimping

Instructions:

- Step 1: Thread about 3" of the wire through a crimp bead, then through the loop on the bar end of the toggle clasp, the back through the crimp bead. Crimp the bead to secure and cut off excess wire and attach the crimp bead cover.
- Step 2: Slide on one 4mm, one 5mm and one 6mm Swarovski Crystal Pearl and then add one Swarovski Rondelle Spacer.
- Step 3: Slide one three 8mm Swarovski Crystal Pearls, alternating them with one Swarovski Rondelle Spacer.
- Step 4: Repeat step 3 using five 10mm Swarovski Crystal Pearls and 5 Swarovski Rondelle Spacer and then again using 5 12mm Swarovski Crystal Pearls and 5 Swarovski Rondelle Spacers.
- Step 5: Repeat step 3 once more using five 14mm Swarovski Crystal Pearls and five Swarovski Rondelle Spacers.
- Step 6: Reverse the pattern, starting with step 3, then step 2 and finally step 1, this time attaching the circle end of the toggle clasp to the wire. Crimp the crimp bead, cut off excess wire and attach the crimp bead cover.

Tip: To add 1" increments to necklace length, add three 4mm pearls to both sides.

Love is Golden

Golden pearls and pendants combine to create this stunning briolette pendant necklace and earrings.



Necklace Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearl	5810	2 pcs	4mm	Crystal Bright Gold	001 306
Briolette Pendant	6010	4 pcs	13x6.5mm	Crystal Golden Shadow	001 GSHA
Small Briolette Pendant	6007	2 pcs	7x4mm	Crystal Golden Shadow	001 GSHA
Small Briolette Pendant	6007	36 pcs	9x5mm	Crystal Golden Shadow	001 GSHA

Supplies:

- 1 TierraCast® 94 6070 12 Heirloom Toggle Clasp (or similar clasp)
- 2 silver crimp beads
- 2 silver crimp bead covers
- 26" 49 strand beading wire
- 42 3mm round silver beads

Earrings

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Briolette Bead	5040	12 pcs	4mm	Crystal Golden Shadow	001 GSHA
Briolette Bead	5040	2 pcs	6mm	Crystal Golden Shadow	001 GSHA
Briolette Pendant	6010	2 pcs	13x6.5mm	Crystal Golden Shadow	001 GSHA
Small Briolette Pendant	6007	8 pcs	7x4mm	Crystal Golden Shadow	001 GSHA
Small Briolette Pendant	6007	6 pcs	9x5mm	Crystal Golden Shadow	001 GSHA

Supplies:

- 2 TierraCast Empire Link 94 3034 12 (or similar link)
- 2 Tierracast Minuet Link 94-3035-12 (or similar link)
- 2 Silver Ear wires
- 15" 22 gauge silver wire
- 4 6mm oval jump rings
- 24 3mm round silver beads

Tools: Round nose pliers, wire cutters, crimping pliers

Skill Level: Necklace – Beginner, Earrings - Intermediate

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings.

Necklace Instructions

- Step 1: Thread about 3" of the wire through a crimp bead, then through the loop on the bar end of the toggle clasp, then back through the crimp bead. Crimp the bead to secure and cut off excess wire and attach the crimp bead cover.
- Step 2: String on 21 6mm Swarovski Crystal Pearls and 21 silver seed beads, alternating them as you go.
- Step 3: String on one 7x4mm and eighteen 9x5mm Swarovski Small Briquette Pendants and four 13x6.5mm Swarovski Briquette Pendants.
- Step 4: Reverse the pattern starting with the eighteen 9x5mm pendants. Attach the circle end of the toggle clasp to the wire. Crimp the crimp bead, cut off excess wire and attach the crimp bead cover.

Earring Instructions

- Step 1: Turn a small loop on one end of the silver wire. String on one 4mm Swarovski Briquette Bead. Bend the wire at the top of the bead and cut off wire leaving approximately 1/4". Turn another small loop at this end. Repeat this step 5 times with 4mm Briquette Beads.
- Step 2: Open one of the loops on one of the 4mm Briquette Beaded eye pins created in Step 1 and attach it to the loop at the bottom of the Empire Link. Close loop to secure. Repeat on other side of Empire Link.
- Step 3: Open the bottom loop of the beaded eye pin from step 2 and attach another 4mm beaded eye pin. Close the loop to secure. Open the loop on the bottom of this beaded eye pin and attach to one end of the Minuet Link. Close loop to secure. Repeat this step on the other side of the Empire Link.
- Step 4: Open the loop on another beaded eye pin and attach to the bottom of the Minuet Link. Close loop to secure and repeat on other side.
- Step 5: Cut a 5" piece of silver wire and form a small loop on the end. String on one 7x4mm Swarovski Small Briquette Pendant, two silver seed beads, one 9x5mm Swarovski Briquette Pendant, and two silver seed beads. Repeat this pattern twice more and end with one more 7x4mm Briquette Pendant. Curve wire to a crescent shape and form a small loop after the last pendant. Cut off excess wire. Open the loops on the ends and attach to the bottom loops of the beaded eye pin attached to the Minuet Link from Step 4.
- Step 5: Open a 6mm oval jump ring and attach it to the 13x6.5 Swarovski Briquette Pendant and then attach it to the center of the Empire Link. Close the jump ring to secure.
- Step 6: Turn a small loop on the silver wire and slide on one 6mm Swarovski Briquette Bead. Trim the wire to about 3/16" of an inch and turn a very small loop at the end (just big enough to hold the bead. Open a 6mm oval jump ring and attach it to the top loop of the bead and attach this to the center loop of the Minuet link.
- Step 7: Repeat steps 1-6 for second earring.

Tip: To add 1" increments to necklace length, add 3 4mm pearls to both sides.

Entwined

This Smoky Mauve bracelet and earring set is an elegant addition to any special day or evening occasion.



Bracelet

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearl	5810	68 pcs	3mm	Crystal White Pearl	001 650
Briolette Bead	5040	16 pcs	6mm	Smoky Mauve	265
Briolette Bead	5040	7 pcs	8mm	Smoky Mauve	265
Round Bead	5000	52 pcs	4mm	Smoky Mauve	265
Round Bead	5000	12 pcs	6mm	Smoky Mauve	265
Round Bead	5000	8 pcs	8mm	Smoky Mauve	265

Supplies:

- 1 5-Hole D Ring Clasp Set - TierraCast® 94-6176 13 (or similar clasp)
- 10 black plated crimp tubes
- 60" beading wire

Earrings

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearl	5810	8 pcs	4mm	Crystal White Pearl	001 650
Xilion Bicone Bead	5328	18 pcs	4mm	Smoky Mauve	265
Briolette Pendant	6010	6 pcs	13x6.5mm	Smoky Mauve	265

Supplies:

- 6 TierraCast® 5mm 3-Hole Bar 94-3162 40
- 2 Add a bead Ear wires in Silver
- 6 2" eye pins in silver
- 6 6mm jump rings in silver

Tools: Wire cutters, crimping pliers, round nose pliers, chain nose pliers

Skill Level: Bracelet & Earrings – Intermediate

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings.

Bracelet Instructions

- Step 1: Cut the wire into 5 equal lengths.
- Step 2: Strand 1: Thread about 3" of one piece of wire through a crimp bead, then through the end loop on one of the D-Rings then back through the crimp bead. Crimp the bead to secure and cut off excess wire.
- Step 3: String on one 4mm Swarovski Round Bead and one 3mm Swarovski Crystal Pearl and repeat 8 times. Add one 4mm Round Bead and then reverse the pattern. Crimp the other end of the beaded wire onto the corresponding end loop of the other D Ring as done is step 2. Cut off excess wire.
- Step 4: Strand 2: Repeat Step 2 using the second hole on the D Ring. String on one 3mm Crystal Pearl, one 4mm Round Bead.

Entwined Bracelet Instructions continued:

- Step 5: String on one 3mm Crystal Pearl, one 8mm Round Bead, one 3mm Crystal Pearl, one 6mm Round Bead, one 4mm Round Bead, one 3mm Crystal Pearl, one 4mm Round Bead, one 6mm Round Bead. Repeat this pattern twice.
- Step 6: String on one 3mm Crystal Pearl, one 8mm Round Bead and one 4mm Round Bead. Crimp wire end to the corresponding loop in the other D Ring as done in step 3.
- Step 7: Strand 3: Repeat Step 2 using the third (center) hole in on the D Ring. String on one 6mm Swarovski Briolette Bead, one 3mm Crystal Pearl, one 6mm Briolette Bead and one 8mm Briolette Bead. Repeat the pattern 6 times and end with one 6mm Briolette Bead, one 3mm Crystal Pearl and one 6mm Briolette Bead. Crimp the end on the other D Ring as done in previous steps.
- Step 8: Strand 4: Repeat Steps 4, 5 & 6, but reverse the pattern.
- Step 9: Strand 5: Repeat Steps 2 & 3.

Earring Instructions:

- Step 1: Add one 4mm Swarovski Xilion Bicone Bead to the "Add a Bead" ear wire.
- Step 2: On one eye pin string on one 4mm Swarovski Xilion Bicone Bead. Repeat with another eye pin. On a third eye pin slide on one 4mm Swarovski Crystal Pearl. Lay the eye pin with the crystal pearl between the two eye pins with the Bicone Beads and slide one of the 3-hole bars onto all three eye pins. Repeat this step 2 more times and add one 4mm Bicone Bead or one 4mm Crystal Pearl to the top of each row. Make a very small loop on the tops of the two eye pins with the Bicone beads (just enough to hold the beads in place) and create a regular loop on the top of the eye pin with the crystal pearl. Trim any excess wire off the eye pins.
- Step 3: Open the loop at the bottom of the ear wire and attach to the loop created in the top of the pearl row in Step 2. Close all loops securely.
- Step 4: Open three 6mm jump rings and attach each one to a Swarovski 13x6.5 Briolette Pendant and to the bottom loops of the eye pins in each Bicone Bead and Pearl row created in step 2.
- Step 5: Repeat steps 1-4 to create other earring.

Tip: To create a longer bracelet you can easily swap out the toggle clasp for a lobster clasp and jump ring and add an extension chain.

CREATE YOUR STYLE

SWAROVSKI

Love Struck

Spike beads and pendants mixed with black metals to create this edgy asymmetrical design.



Necklace:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Spike Bead	5747	21 pcs	12x6	Crystal	001
Spike Bead	5747	26 pcs	16x8	Crystal	001
Spike Pendants	6480	1 pc	18mm	Crystal	001
Spike Pendant	6480	1 pc	28mm	Crystal	001
Spike Pendant	6480	1 pc	39mm	Crystal	001

Supplies:

27"	49 Strand Beading Wire
3	TierraCast® 94-3102 13 Drilled Hammertone Rectangle Links
1	"S" Hook Clasp in black
13	TierraCast® 93-0450 13 - 7mm metal spacer bead in black (or similar bead)
2	Crimp Tubes in black
6	8mm jump rings in black
3	6mm jump rings in black
2	4mm jump rings in black

Earrings:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Spike Bead	5747	2 pcs	12x6	Crystal	001
Spike Bead	5747	2 pcs	16x8	Crystal	001
Xilion Bicone Bead	5328	2 pcs	4mm	Crystal	001

Supplies:

2	TierraCast® 94-3102 13 Drilled Hammertone Rectangle Links (or similar link)
2	TierraCast® 93-0450 13 - 7mm metal spacer bead in black (or similar bead)
2	Add a Bead ear wires in black
2	Ball tip headpins in black

Tools: Wire cutters, crimping pliers, round nose pliers, chain nose pliers.

Skill Level: Necklace & Earrings – Beginner

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings

Necklace Instructions:

- Step 1: Thread about 3" of wire through a crimp bead, then through one of the 8mm jump rings and back through the crimp bead. Crimp the bead to secure and cut off excess wire.
- Step 2: String on one 12x6mm Swarovski Spike Bead, one 16x8mm Swarovski Spike Bead, one 12x6mm Spike Bead, one 16x8mm Spike Bead, one 12x6mm Spike Bead and one 7mm black metal spacer bead.
- Step 3: Repeat the pattern in Step 2, but add one 16x8mm Spike Bead and one 12x6mm Spike Bead before the 7mm black metal spacer bead. Repeat this pattern twice.
- Step 4: String on one 7mm black metal spacer bead, one 12x6mm Spike Bead, one 16x8mm Spike Bead, one 12x6mm Spike Bead and two 7mm black metal spacer beads. Repeat this pattern twice, but in the last sequence only use one 7mm black metal spacer bead.
- Step 5: String one three 16x8mm Spike Beads and one 7mm black metal spacer bead. Repeat this pattern three times, but omit the 7mm black spacer bead in the last sequence.
- Step 6: Crimp the end of the wire to an 8mm jump ring as done in Step 1. Open one end of the "S" Clasp slightly and slide it onto the jump ring. Press this end of the clasp to secure.
- Step 7: Open an 8mm jump ring and attach to the hole in one of the rectangle links and to the 18mm Swarovski Spike Pendant. Close the jump ring to secure.
- Step 8: Open a 6mm jump ring and attach to the hole in the other side of the rectangle link and add this in between the first double 7mm black metal spacer beads on the necklace (the first set of spacer beads to the right of the "S" clasp). Close the jump ring to secure.
- Step 9: Repeat steps 7 & 8 using the 28mm Swarovski Spike Pendant and attach it between the second double 7mm black spacer beads. Close the jump ring to secure.
- Step 10: Open an 8mm jump ring and attach to the 39mm Swarovski Spike Bead. Attach two 4mm jump rings to the opened 8mm jump ring and close the 8mm jump ring. Open a second 8mm jump ring and attach to the two 4mm jump rings and to one hole in the third rectangle link. Close the jump ring to secure.
- Step 11: Open a 6mm jump ring and attach to the top of the rectangle link created in step 10 and between the last two 7mm black spacer beads on the necklace. Close the jump ring to secure. (This largest Spike Bead will be in the middle of the necklace.)

Earring Instructions:

- Step 1: String on one 12x6mm Swarovski Spike Bead, one 7mm black metal spacer bead and one 16x8mm Swarovski Spike Bead onto the ball tip headpin. Turn a simple loop at the top of the bead and cut off excess.
- Step 2: Open the headpin loop from Step 1 slightly and attach it to the hole in one of the rectangle links. Close the loop to secure.
- Step 3: Add a 4mm Swarovski Bicone Bead to the Add a Bead ear wire. Open the loop at the bottom of the ear wire and attach to the top of the rectangle link. Close the loop to secure.
- Step 4: Repeat Steps 1-3 to create second earring.

Tip: To create a symmetrical design create the necklace using only the 39mm Swarovski Crystal Spike Pendant.

CREATE
YOUR STYLE

SWAROVSKI

Happily Ever After

Be the topic of conversation at your next event with this art deco jewelry design made with the new Swarovski Sun Pendant.



Necklace:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Sun Pendants	6724	1 pc	33mm	Crystal AB	001 AB
Sun Pendants	6724	6 pcs	19mm	Crystal AB	001 AB
Sun Pendants	6724	10 pcs	12mm	Crystal AB	001 AB
Crystal Pearls	5810	3 pcs	4mm	Crystal White	001 650
Crystal Pearls	5810	66 pcs	6mm	Crystal White	001 650
Crystal Pearls	5810	7 pcs	8mm	Crystal White	001 650

Supplies:

- 25" 49 Strand Beading Wire
- 1 Toggle Clasp in Copper or Brass
- 1 Medium to large Pinch Bail in copper or brass
- 30" Unsoldered cable chain (6x4) in copper or brass (you will need 99 links of chain to create the necklace)
- 35 Medium oval jump rings in copper or brass
- 2 Crimp Tubes in copper or brass
- 6 8mm round jump rings in copper or brass
- 10 8mm oval jump rings in copper or brass
- 13" 20 gauge brass or copper wire

Earrings:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Sun Pendants	6724	6 pcs	12mm	Crystal AB	001 AB
Crystal Pearls	5810	2 pcs	4mm	Crystal White	001 650
Crystal Pearls	5810	2 pcs	6mm	Crystal White	001 650
Crystal Pearls	5810	2 pcs	8mm	Crystal White	001 650

Supplies:

- 6 6mm oval jump rings in copper or brass
- 2 Add a Bead ear wires in copper or brass
- 15" 20 gauge brass or copper wire

Tools: Crimping pliers, wire cutters, round nose pliers, chain nose pliers

Skill Level: Necklace & Earrings - Intermediate

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings, basic wire work.

Necklace Instructions:

- Step 1: Thread about 3" of wire through a crimp bead, then through the loop in the bar end of the toggle clasp and back through the crimp bead. Crimp the bead to secure and cut off excess wire.
- Step 2: String on 63 6mm Swarovski Crystal Pearls and crimp the other end of beaded wire using the circle end of the toggle clasp as done in step 1.
- Step 3: Open 5 8mm oval jump rings and attach to the 12mm Swarovski Sun Pendants. Attach one between the 9th and 10th pearl of the necklace created above. Skip two pearls and add another. Repeat for the remaining 3 pendants. *(Note: Be careful to make sure that all the pendants are facing the same way – with the AB coating towards the back of the necklace.)* Close all jump rings to secure. Repeat this step on the other end of the necklace.
- Step 4: Cut two sections of chain with 9 links, two with 13 links, and two with 17 links.
- Step 5: Open 6 8mm jump rings and connect to the 19mm Swarovski Sun Pendants. Connect them all to the center links in the chains cut in step 4. Close the jump rings to secure.
- Step 6: Open the two end links of one of the 9 link chains connected to the pendant and attach one link between the 18th and 19th pearl on the necklace. Attach the other side of the chain between the 21st and 22nd pearls in the necklace. Close loops of the chain to secure. Repeat this step on the other side of the necklace. *(Note: Be careful to make sure that all the pendants are facing the same way.)*
- Step 7: Repeat step 6 using the 13 link chain & pendant and connect one end between the 22nd and 23rd pearls and the other end between the 25th and 26th pearls. Close the loops to secure. Repeat this step on the other side of the necklace. *(Note: Be careful to make sure that all the pendants are facing the same way.)*
- Step 8: Repeat Step 7 using the 17 link chain and pendant connecting one link between the 26th and 27th pearl and the other end between the 29th and 30th pearl. Close the loops to secure. Repeat this step on the other side of the necklace. *(Note: Be careful to make sure that all the pendants are facing the same way.)*
- Step 9: Attach the pendant bail to the 33mm Swarovski Sun Pendant and pinch it to secure. Cut a 21 link section of section and slide it through the bail. Open the links at both ends and connect one between the 30th and 31st pearl and the other side of the chain between the 33rd and 34th pearl. Close the loops to secure. *(Note: Be careful to make sure that all the pendants are facing the same way.)*
- Step 10: Create a very small loop at the bottom of the wire and slide on one 8mm Swarovski Crystal Pearl. Turn a loop at the top of the pearl and cut excess wire. Repeat this step 6 times. Set aside excess wire for below steps.
- Step 11: Create a chain using 5 6mm oval jump rings. Attach one of the 8mm pearls from step 10 to the third link. Open the end links and attach one end between the 19th and 20th pearl in the necklace and the other end between the 20th and 21st pearl. Repeat this step for the other side of the necklace.
- Step 12: Turn a loop at the bottom of the wire leftover from step 10. Slide on one 4mm Swarovski Crystal Pearl and turn a loop at the top. Cut off excess wire. Attach one end of this 4mm pearl to the loop of one of the 8mm pearls created in step 10. Create a chain using 5 6mm oval jump rings and attach the top loop of the 4mm pearl to the third link. Open the links on the ends of this chain and connect one end between the 23rd and 24th pearl and the other end between the 24th and 25th pearl in the necklace. Repeat this step on the other side of the necklace.
- Step 13: Repeat Step 12, but use a 6mm Swarovski Crystal Pearl. Create a 5 link chain as done in step 12 and attach the pearls to the center link. Attach this chain between the 27th and 28th and 28th 29th pearls in the necklace as done in the previous steps. Repeat on other side of necklace.
- Step 14: Repeat step 13 using a 4mm and 6mm Swarovski pearl, attaching the 6mm pearl to the last 8mm pearl created in step 10 and then attach the 4mm pearl to the 6mm pearl. Create the last 5 link chain using the 6mm oval jump rings and attach the 4mm pearl to the middle link of this chain. Attach one end of the chain between the 31st and 32nd pearl and the other end between the 32nd and 33rd pearl.

Earring Instructions:

- Step 1: Create a very small loop at the bottom of the wire and slide on one 8mm Swarovski Crystal Pearl. Turn a loop at the top of the pearl and cut excess wire. Repeat this step once. Set aside excess wire for below steps.
- Step 2: Create a loop at the bottom of the wire and slide on a 6mm Swarovski Crystal Pearl. Turn another loop at the top and trim excess wire. Repeat this step once.
- Step 3: Attach the 6mm pearl created in step 2 to the loop at the top of the 8mm pearl created in step 1. Repeat once.

Tip: Use a jewelry wire jig to easily create the diamond shaped wire for these earrings.

CREATE
YOUR STYLE

SWAROVSKI

Two Hearts Now One

The heart shaped clasp and earring connectors update this traditional design made with crystals and crystal pearls from Swarovski.



Necklace:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	18 pcs	6mm	Crystal White	001 650
Crystal Pearls	5810	4 pcs	8mm	Crystal White	001 650
Xilion Bicone Beads	5328	18 pcs	4mm	Crystal	001
Xilion Bicone Beads	5328	25 pcs	6mm	Crystal	001
Xilion Bicone Beads	5328	4 pcs.	8mm	Crystal	001
Xilion Square Rondelle or Rondelle Spacer	77806 or 77506	16 pcs	6mm	Crystal/Rhodium	001 H

Supplies:

27"	Beading Wire
1	TierraCast® Sacred Heart Toggle Clasp in silver 94-613 12 (or similar clasp)
2	Crimp beads in silver
2	Crimp bead covers in silver
35	3mm round silver beads

Earrings:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	2 pcs	4mm	Crystal White	001 650
Xilion Bicone Beads	5328	50 pcs	2.5mm	Crystal	001
Xilion Bicone Beads	5328	6 pcs	6mm	Crystal	001
Xilion Bicone Beads	5328	6 pcs.	4mm	Crystal	001
Xilion Square Rondelle or Rondelle Spacer	77806 or 77506	16 pcs	6mm	Crystal/Rhodium	001 H

Supplies:

2	TierraCast® 94-3094 3-1 Vine Heart connector (or similar connector)
2	Silver ear wires
20"	20 gauge silver wire
6	3mm silver beads

Tools: Wire cutters, crimping pliers, round nose pliers, chain nose pliers

Skill Level: Necklace – Beginner, Earrings – Intermediate

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings.

Necklace Instructions:

- Step 1: Thread about 3" of wire through a crimp bead, then through the loop in the bar end of the toggle clasp and back through the crimp bead. Crimp the bead to secure and cut off excess wire. Attach the crimp bead cover over the crimp bead.
- Step 2: String on one silver seed bead, one 6mm Swarovski Crystal Pearl, one 4mm Swarovski Xilion Bicone Bead, one 6mm Swarovski Bicone Bead, one 4mm Swarovski Xilion Bicone Bead, one silver seed bead and one 6mm Swarovski Crystal Pearl.
- Step 3: String on one silver seed bead, one 6mm bicone, one Swarovski Rondelle Spacer, one 8mm bicone, one Rondelle Spacer, one 6mm bicone.
- Step 4: Repeat the sequence in step 2.
- Step 5: String on one silver seed bead, one 6mm bicone, one Rondelle spacer, one 8mm Swarovski Crystal Pearl, one Rondelle spacer and one 6mm bicone.
- Step 6: Repeat step 2 and then repeat step 3.
- Step 7: Repeat steps 2, 5, 2, 3, 2, 5, 2, 3, 2, 5, and 2.
- Step 8: Add one silver seed bead and then attach to the heart shape part of the clasp as done in step 1. Cut off excess wire.

Earring Instructions:

- Step 1: Create a loop at the end of the wire and string on one 4mm Swarovski Crystal Pearl. Turn a loop at the top of the pearl and cut off excess wire. Repeat once.
- Step 2: Create a small loop at the bottom of the wire and string on one 6mm Swarovski Xilion Bicone Bead and one silver seed bead. Turn a loop at the top of the bead and cut off excess wire. Repeat 5 times.
- Step 3: Create a small loop at the bottom of the wire and string on one 4mm Swarovski Xilion Bicone Beads and 8 2.5mm Swarovski Xilion Bicone Beads. Turn a loop at the top and cut off excess wire. Repeat this step three times and then repeat this step twice using 9 2.5mm bicone beads.
- Step 4: Attach one of 6mm bicone beads from step 2 to each of the 4 & 2.5mm bicone bead strands from step 3, attaching it to the loop near the 4mm bead.
- Step 5: Attach one of the strands from step 4 with 9 2.5mm bicone beads to the center loop of the heart connector. Attach one of the strands from step 4 with 8 2.5mm beads to the loop on one side and another to the loop on the other side of the heart connector.
- Step 6: Attach the pearl made in step 1 to the loop at the top of the heart connector and to the loop at the bottom of the ear wire.
- Step 7: Repeat steps 5 & 6 to finish second earring.

CREATE YOUR STYLE

SWAROVSKI

I Do!

The new Swarovski Arrow beads will point you in the right direction when wearing this "frilly" heart shaped necklace, while the white patina effect on the crystals will have you thinking about romantic times of yesteryear.



Necklace: Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	10 pcs	6mm	Crystal White	001 650
Crystal Pearls	5810	12 pcs	4mm	Crystal White	001 650
Crystal Pearls	5810	50 pcs	3mm	Crystal White	001 650
Arrow Beads	5748	20 pcs	12mm	Crystal White Patina	001 WHIPA
Wild Heart Pendant	6240	1 pc	27mm	Crystal White Patina	001 WHIPA
Xilion Pendant	6428	48 pcs	6mm	Crystal White Patina	001 WHIPA

Supplies:

- 26" Beading Wire
- 1 Tierracast® 94-6217-12 Claddagh Clasp Set (or similar clasp)
- 15" 22 gauge silver wire
- 4 Crimp beads in silver
- 2 8mm jump rings in silver
- 1 Tierracast® 94-5783 12 large Hammertone bail (or similar pendant bail)

Earrings:

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	2 pcs	6mm	Crystal White	001 650
Arrow Beads	5748	4 pcs	12mm	Crystal White Patina	001 WHIPA
Xilion Bicone Bead	5328	2 pcs	4mm	Crystal	001
Wild Heart Pendant	6240	2 pcs	17mm	Crystal White Patina	001 WHIPA

Supplies:

- 2 Add a Bead ear wires in silver
- 2 Tierracast® 94-5780 Nouveau bail (or similar pendant bail)
- 2 8mm jump rings in silver
- 8" 20 gauge silver wire

Tools: Wire cutters, crimping pliers, round nose pliers, chain nose pliers

Skill Level: Necklace – Intermediate, Earrings – Beginner

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings.

Necklace Instructions:

- Step 1: Thread about 3" of wire through a crimp bead, then through the loop in the bar end of the toggle clasp and back through the crimp bead. Crimp the bead to secure and cut off excess wire.
- Step 2: String on one 3mm Swarovski Crystal Pearl, one 4mm Swarovski Crystal Pearl, one 3mm Swarovski Crystal Pearl, one 12mm Swarovski Bead, article 5748, one 6mm Swarovski Crystal Pearl and one 12mm Swarovski Bead, article 5748.
- Step 3: Repeat the pattern above 4 times and end with one 3mm Swarovski Crystal Pearl, one 4mm Swarovski Crystal Pearl and one more 3mm Swarovski Crystal Pearl.
- Step 4: Crimp this end to one of the 8mm jump rings. Trim excess wire.
- Step 5: Repeat steps 1-4 to create the other side of the necklace, using the circle end of the toggle clasp in step 1.
- Step 6: Make a slight bend on one end of the silver wire (to prevent crystals from falling off) and loosely string on three 3mm Swarovski Crystal Pearls.
- Step 7: String on three 6mm Xilion Pendants and one 3mm pearl. Repeat this step 7 times, then string on 5 more 3mm pearls. (Continue to string the pendants and pearls loosely on the wire.)
- Step 8: String on three 6mm Xilion Pendants and one 3mm pearl. Repeat this step 7 times, then string on 3 more 3mm pearls, continuing to string it loosely.
- Step 9: Make a small bend in the other end of the wire to prevent the crystals from falling off and form the strung wire into a heart shape, making the center of the heart where the five 3mm pearls are from step 7. Push the crystals close together on one side of the heart and fold the wire back to secure. Repeat for the other side of the heart, then wire wrap the two ends together at the bottom of the heart to secure. Make this wire wrapped section only about 3/16 of an inch. (The large pendant will cover this wire in the next step.)
- Step 10: Place the pendant bail facing down over the wrapped wire at the bottom of the heart and attach the 27mm Swarovski Wild Heart Pendant. Gently pinch the bail to secure.
- Step 11: Open the jump ring at the end of the necklace strand made in step 4. Attach the jump ring to the crystal heart between the 3rd and 4th Xilion Pendant grouping to the left of the center of the heart. Repeat this step using the other necklace strand made in step 5 and attach it between the 3rd and 4th Xilion Pendant grouping to the right of the center of the heart. Close jump rings securely.

Earring Instructions:

- Step 1: Create a loop at the bottom of the silver wire and string on one 12mm Swarovski Arrow Bead, one 6mm Swarovski Crystal Pearl and one more 12mm Arrow Bead. Turn a loop at the top of the bead and cut off excess wire.
- Step 2: Open an 8mm jump ring and attach it to one end of the bead strand made in step 1 and to one of the pendant bails. Close the jump ring to secure.
- Step 3: Attach the 17mm Swarovski Wild Heart Pendant to the bail and gently close the bail into the pendant holes.
- Step 4: Attach the 4mm Swarovski Xilion Bicone Bead to the Add a Bead ear wire. Open the loop at the bottom of the ear wire and attach to the top loop of the strand made in steps 1-3. Repeat steps 1-4 to create second earring.

Tip: Make sure the crystals on the wire are loose when forming the heart shape so they don't crack or chip. You can make them snug once the heart shape is formed.

Soul Mates

The new Swarovski BeCharmed Pearl beads fit snugly into the new Swarovski Dome beads to create this new era of pearl earrings.



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal BeCharmed Pearls	5890	2 pcs	14mm	Crystal White	001 650
Briolette Bead	5040	2 pcs	6mm	Smoky Mauve	265
Round Bead	5000	2 pcs	4mm	Smoky Mauve	265
Dome Bead	5541	2 pcs	15mm	Smoky Mauve	265

Supplies:

2 Silver Ear wires
2 Ball end head pins

Tools: Wire cutters, round nose pliers, chain nose pliers

Skill Level: Beginner

Techniques: Basic stringing, creating simple loops.

Instructions:

- Step 1: Slide the Swarovski Dome Bead onto the head pin, then add the Swarovski BeCharmed Bead, the Swarovski Briolette Bead and the Swarovski Round Bead.
- Step 2: Turn a loop at the top of the round bead and cut off the excess wire. Attach the ear wire and close the loop to secure. Repeat steps 1 & 2 to create second earring.

Worth the Wait

Beaded chains flowing from the new Swarovski Dome beads create an eye catching earring that can be worn for all your special occasions.



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	12 pcs	3mm	Crystal White	001 650
Xilion Bicone Bead	5328	6 pcs	4mm	Crystal	001
Dome Bead	5541	2 pcs	8mm	Crystal	001
Dome Bead	5541	2 pcs	11mm	Crystal	001

Supplies:

2 Add a Bead Ear Wires in Silver
2 Silver Eye Pins
10" Small silver cable chain
8" 20 Gauge silver wire

Tools: Wire cutters, round nose pliers, chain nose pliers

Skill Level: Intermediate

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings.

Instructions:

- Step 1: Slide one 8mm Swarovski Dome Bead onto the eye pin, then add a 4mm Swarovski Crystal Pearl and one 11mm Swarovski Dome Bead. Turn a loop at the top of the bead and cut off the excess wire.
- Step 2: Cut two pieces of 1/4" chain, two pieces of 1/2" chain, two pieces of 3/4" chain, & one piece of 1 1/4" chain.
- Step 3: Make a very small loop on the bottom of the silver wire. String on one 3mm Swarovski Crystal Pearl. Turn a loop at the top of the pearl and cut off excess wire. Repeat this step 3 times.
- Step 4: Repeat step 3 three more times with the 4mm Swarovski Xilion Bicone Beads.
- Step 5: Attach one of the Swarovski Crystal Pearls created in step 3 to the bottom link of one 1/4" piece of chain by opening the loop slightly. Close the loop to secure. Repeat with the other 1/4" chain. Similarly, attach the other two Swarovski Crystal Pearls created in step 3 to the bottom link of the 3/4" chains.
- Step 6: Attach the Swarovski Xilion Bicone Beads created in step 4 to the bottom links of the 1/2" chains and 1 1/4" chains as done with the pearls in step 5.
- Step 7: Open the loop of the eye pin at the bottom of the 8mm Swarovski Dome Bead. String on the chains in this order: 1/4", 1/2", 3/4", 1 1/4", 3/4", 1/2", 1/4". Close the loop to secure.
- Step 8: Attach the 4mm Swarovski Crystal Pearl to the Add a Bead ear wire. Open the loop at the bottom of the ear wire and attach to the loop at the top of the 1mm Swarovski Dome Bead. Repeat steps 1-8 to create second earring.

CREATE YOUR STYLE

SWAROVSKI

Forever

Add a little edginess to your attire with these chain maille and crystal cross earrings.



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Cross Bead	5378	2 pcs	14mm	Smoky Mauve	265

Supplies:

- 2 Black headpins
- 2 Black ear wires
- 22 6mm black jump rings
- 2 Tierracast® small 3 hole D-Ring connector 94-6183 (or similar connector)

Tools: Round nose pliers, chain nose pliers, wire cutters.

Skill Level: Beginner

Techniques: Basic stringing, creating simple loops, opening & closing jump rings

Instructions:

- Step 1: Slide the Swarovski Heart Bead onto the headpin and turn a loop at the top of the bead. Cut off excess wire.
- Step 2: Open three jump rings and attach to the three holes in the D Ring connector. Close the jump rings.
- Step 3: Open one jump ring and connect it to the first and second jump ring attached to the D Ring connector in step 2. Close the jump ring. Open another jump ring and connect it to the second and third jump ring attached to the D Ring connector. Close the jump ring.
- Step 4: Open two jump rings and connect both to the two jump rings attached in step 3. (All four jump rings will be connected.)
- Step 5: Repeat step 4 two more times to create a chain of four double jump rings.
- Step 6: Open the loop at the top of the cross bead and attach to the two bottom rings in the chain. Repeat steps 1-6 to create the second earring

A Perfect Match

The new Swarovski Crystalactite Pendants add sophistication and glamour to these otherwise simplistic earrings.



Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
BeCharmed Fortune Bead	5929	2 pcs	14mm	Crystal AB	001 AB
Xilion Bicone Bead	5328	4 pcs	8mm	Crystal	001
Xilion Bicone Bead	5328	2 pcs	5mm	Crystal	001
Crystalactite Pendant	6017/G	2 pcs	30mm	Crystal	001

Supplies:

2 Add a Bead ear wires in silver
2 2" silver eye pins

Tools: Round nose pliers, chain nose pliers, wire cutters

Skill Level: Beginner

Techniques: Basic stringing, crimping, creating simple loops, opening & closing jump rings.

Instructions:

- Step 1: Slide on one Swarovski 8mm Xilion Bicone to the eye pin, then add one Swarovski Fortune BeCharmed Bead and another 8mm bicone. Turn a loop at the top of the bicone bead.
- Step 2: Open the loop at the bottom of the eye pin and attach the Swarovski Crystalactite Pendant. Close the loop to secure.
- Step 3: Add the 5mm Swarovski Xilion Bicone Bead to the Add a Bead ear wire. Open the loop at the bottom of the ear wire and attach it to the loop at the top of the 8mm bicone created in step 1. Repeat steps 1-3 to create second earring.