

CREATE
YOUR STYLE

Fall/Winter 2016/2017 Innovations Mini Projects



Royal Coins Necklace



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Crystal Pearls	5810	90 pcs	6mm	Scarabaeus Green	001 946
Crystal Pearls	5840	9 pcs	12mm	Scarabaeus Green	001 946
Crystal Pearls	5810	18 pcs	8mm	Iridescent Purple	001 943
Mini Beads	5052	20 pcs	8mm	Amethyst	204
Beads	5328	22 pcs	4mm	Light Amethyst	212
BeCharmed	80301	3 pcs	10.5mm	Light Amethyst	212

Supplies:

40" 0.014 beading wire

2 3mm crimp beads

14" 20 gauge wire

6 7mm Bead Aligners TierraCast® 94-5754-12

6 1" Hammertone Disk Link TierraCast® 94-3148-40 or similar disk link

Adhesive tape

Instructions

Step 1: Cut 20 gauge wire into seven 2" pieces. Using one piece of wire make a simple loop. Slide on one 8mm 5052 in Amethyst, one 12mm baroque pearl, and one 8mm 5052 in Amethyst, make a simple loop. Repeat 6 more times. Set aside.

Step 2: Using one link made in Step 1 attach to one end of 1" Hammertone Disk. Using a second link made in Step 1 attach to opposite side of Hammertone Disk. Continue making these links until you have used all the links and Hammertone disks. Set aside.

Step 3: Cut beading wire into two 20" pieces. Using one piece tape the end and slide on one 4mm bicone, 70 6mm Scarabaeus Green pearls and one bicone and tape the other end. Set aside.

Royal Coins Necklace - continued

- Step 4: Using second piece of beading wire tape one end, then slide on one bicone, five 6mm Scarabaeus Green pearls, one bicone, one amethyst mini bead, one bicone, three 8mm Iridescent Purple Pearls, one bicone, one bead aligner, one BeCharmed bead, one bead aligner, one bicone, three 8mm Iridescent Purple Pearls, one bicone, one amethyst mini bead, one bicone. Repeat this pattern 2 more times ending with one bicone. Tape other end and set aside.
- Step 5: Take the two strands made in Steps 3 & 4 and slide them both through one 12mm Baroque Pearl. Then slide on one crimp bead. Take this and crimp the two strands directly to the end link in the set of links created in Step 2.
- Step 6: Now gently twist (braid) the two beaded strands together and then slide them both through one 12mm Baroque Pearl. Then slide on one crimp bead. Take this and crimp to the opposite side of links.

Tubular Spikes Necklace



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Rondelle Bead	5045	9 pcs	8mm	Jet	280
BeCharmed	80912	1 pc	11.5mm	Crystal Silver Night/Jet	001 SINI/280
BeCharmed	80921	1 pc	13mm	Crystal Silver Night	001 SINI
Pendants	6480	1 pc	28mm	Crystal Silver Night	001 SINI

Supplies:

13" 20 gauge wire

1 8mm jump ring

18" Brass Cable Chain 6x4mm TierraCast® 20-0425-12 or similar chain

4 7mm Classic Bead Aligners TierraCast® 94-5755-61

1 1/2" Anna Toggle TierraCast® 94-6154-12 or similar toggle

Instructions

Step 1: Cut chain into two 2" pieces and two 7" pieces.

Step 2: Cut wire into two 2" pieces and nine 1" pieces.

Step 3: Using one 2" piece of wire make a simple loop. Slide on one bead aligner, one BeCharmed Bead, and one bead aligner, make a simple loop. Repeat one more time with second BeCharmed Bead and set aside.

Step 4: Using one 1" piece of wire make a simple loop. Slide on one Rondelle bead and make a simple loop. Repeat 8 more times and set aside.

Step 5: Using the jump ring attach to the Spike Pendant and one of the BeCharmed bead links from Step 3. Then attach three of the links made in Step 4. Then attach second BeCharmed bead link from Step 3.

Step 6: Using a 2" piece of chain attach to the top of the drop that was made in Step 5. Then attach three of the links made in Step 4. Then attach a 7" piece of chain. Then attach one side of the toggle. Repeat this step to make the other side of the necklace.

CREATE
YOUR STYLE

SWAROVSKI

All Fired Up Necklace



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Kaputt Pendant	6911	1	36mm	Crystal volcano P	001 VOL
Bicone Bead	5328	51	4mm	Crystal metallic sunshine	001 METSH
Rondelle Bead	5045	24	8mm	Crystal metallic sunshine	001 METSH
Rondelle Bead	5045	24	6mm	Crystal metallic sunshine	001 METSH

Supplies:

20" 0.014 beading wire

2 crimp beads

1 Craftsman toggle clasp TierraCast® 94-6205-25 or similar toggle

1 Large Hammertone bail TierraCast® 94-5783-25 or similar bail

Instructions

Step 1: Crimp one half of the toggle clasp to the beading wire.

Step 2: String one (1) 4mm 5328 bicone, (1) 6mm Rondelle, (1) 4mm 5328 bicone, (1) 8mm Rondelle. Repeat this pattern 11 times more. String (3) 4mm 5328 bicones. String (1) 8mm Rondelle, (1) 4mm 5328 bicone, (1) 6mm Rondelle, (1) 4mm 5328 bicone. Repeat this pattern 11 times more.

Step 3: Crimp the second half of the toggle clasp to complete the necklace.

Step 4: Slip the necklace, from steps 1-2 into the pendant bail. Next attach the pendant bail to the Kaputt pendant. Apply finger pressure to squeeze the bail closed around the pendant.

Not Your Mama's Chandelier Earrings



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328	44	3mm	Crystal light chrome	001 LTCH
Beads	5601	4	6mm	Crystal light chrome	001 LTCH
Pendants	6106	6	16mm	Crystal light chrome	001 LTCH

Supplies:

- 1 pair ear wires
- 12" 22g wire
- 6 oval jump rings

Instructions

- Step 1: Cut wire into two equal pieces.
- Step 2: Using one piece of wire, create a loop in the center with your round nose pliers. On one side of the loop, slip on (1) 3mm 5328, (1) 6mm 5601 and (1) 3mm 5328 bead, then create another loop; remember to keep the loops in the same direction. Repeat this step for the other side of the middle loop. Crisscross the tails of the wire (the shape should resemble a triangle). On each tail, slip on (9) 3mm 5328 beads. Using the two tails create a wire wrapped loop.
- Step 3: Using one jump ring, attach one 6106 16mm pendant to each loop.
- Step 4: Attach one ear wire to the top loop.
- Step 5: Repeat steps 1-4 for the second pair.

Skullcap Earrings



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Sew-on	3188	2	3mm	Crystal light chrome	001 LTCH
Beads	5750	2	13mm	Crystal light chrome	001 LTCH

Supplies:

- 1 pair ear wires
- 6 links of 9x6mm embossed brass cable chain
- 4 links of 5x6mm brass cable chain
- 2 18mm Skully buttons TierraCast® 94-6571-12
- 2 2" balled headpins

Instructions

- Step 1: Attach one end of two links of 5x6mm chain to the back of the button (from the loop). Attach one end of three links of 9x6mm chain to the back of the button (on the same loop). The chains should face in the opposite direction.
- Step 2: With (1) balled headpin, slip on (1) 13mm skull bead 5750 and (1) 3mm 3188 sew-on stone. Create a wired loop to close.
- Step 3: Open the unattached 9x6mm link and slip on the skull bead from step 2. Close link
- Step 4: Attach one ear wire to the unattached 5x6mm link.
- Step 5: Repeat steps 1-4 for the second pair.

Beetle Mania Necklace



Materials

Swarovski crystal

Product Group	Article No.	Amount	Size	Color	Color Code
Kaputt Pendant	6911	3	26mm	Crystal Scarabaeus green	001 SCGR
Pearls	5810	28	10mm	Crystal Scarabaeus green	001 946

Supplies:

- 2.5ft 20g wire
- 1 lobster clasp
- 4 links 9x6mm embossed cable chain
- 3 links 8x5mm brass cable chain

Instructions

- Step 1: Create a simple loop on each side of the 28 10mm 5810 pearls.
- Step 2: Link together (11) 10mm 5810 pearls together from step 1 and (1) 8x5 brass cable chain link.
- Step 3: To the cable chain link add; (1) 5810 10mm pearl link and (1) 8x5mm brass cable chain link. Repeat once.
- Step 4: To the end brass cable chain link; link together 11 10mm 5810 pearls links from step 1. Set aside.
- Step 5: Attach (1) 9x6mm embossed cable chain to (1) Kaputt 26mm pendant. Attach (1) 10mm 5810 pearl link made in step 1. Repeat once. Set aside.
- Step 6: Attach (1) 9x6mm embossed cable chain to (1) Kaputt 26mm pendant. Attach (2) 10mm 5810 pearl link made in step 1.
- Step 7: Lay out the necklace from Step 4. Attach the component made in step 6 to the center 8x5mm brass cable chain link. Attach the two components made in step 5 to the remaining 8x5 brass cable links.
- Step 8: Attach the lobster clasp to one end of the necklace and the remaining 9x6mm embossed cable chain link to the opposite side for the closure.

Scarabaeus Delight Earrings



Materials

Swarovski crystal

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328	4	3mm	Crystal Scarabaeus green	001 SCGR
Beads	5040	2	6mm	Crystal Scarabaeus green	001 SCGR
Kaputt Pendant	6913	2	28mm	Crystal Scarabaeus green	001 SCGR
Pendant	6428	8	8mm	Crystal Scarabaeus green	001 SCGR

Supplies:

- 1 pair ear wires
- 3" 20g wire
- 8 large oval jump rings
- 16 small oval jump rings
- 2 6-hole end bar TierraCast® 94-3169-25 or similar end bar

Instructions

- Step 1: Attach (2) large jump rings to (1) Kaputt pendant. Attach (2) small jump rings to the large rings just added. Attach (2) large jump rings to the small rings just added and to the single loop on the 6-hole end bar. Repeat once and set aside.
- Step 2: Attach (1) small jump ring to each of the 8mm 6428 round pendants for a total of 8. Set aside.
- Step 3: Attach one small jump ring to the 3rd and 4th loop of the 6-hole end bar. Repeat for the second pair.
- Step 4: Attach (1) component from step 2 to hole #1, 2, 5, & 6 on the 6-hole end bar. Remember to keep the pendants all facing the same direction. Repeat for the second pair.
- Step 5: Cut the wire into two equal pieces. Using one piece, create a simple loop and slip on (1) 3mm 5328, (1) 6mm 5040 and (1) 3mm 5328 and close the wire with a simple loop. Repeat once.
- Step 6: Attach the component made in step 5 to the small jump rings in hole #3 & 4 on the 6-hole end bar. Repeat for the second pair.
- Step 7: Attach ear wires to the remaining simple loop on the component made in step 5.

Swinging Pendulum Earrings



Materials

Swarovski crystal

Product Group	Article No.	Amount	Size	Color	Color Code
Pendant	5514	6	8x5.5mm	Crystal Silver Night	001 SINI
Pendant	5514	4	10x7mm	Crystal Silver Night	001 SINI

Supplies:

- 1 pair ear wires
- 6" small cable chain
- 5" 20g wire
- 2 small jump rings

Instructions

- Step 1: Cut wire into two equal pieces. Cut chain into 4 equal pieces. Set aside
- Step 2: Using one piece of wire, create a simple loop and slide on (1) 8x5.5mm 5514, (1) 10x7mm 5514, (1) 8x5.5mm 5514, (1) 10x7mm 5514 and (1) 8x5.5mm 5514. While holding the beads against the loop made, gently curve the wire. Close the wire with a simple loop. Repeat for second pair.
- Step 3: Attach two pieces of chain, one on each simple loop made in step 2. Repeat for second pair.
- Step 4: Attach one jump ring to each of the chain pieces. Repeat for second pair.
- Step 5: Attach one ear wire to the jump ring in step 4. Repeat for second pair.

Swinging Pendulum Necklace



Materials

Swarovski crystal

Product Group	Article No.	Amount	Size	Color	Color Code
Pendant	5514	4	8x5.5mm	Crystal Silver Night	001 SINI
Pendant	5514	5	10x7mm	Crystal Silver Night	001 SINI

Supplies:

- 1 Anna's 3/8" toggle clasp TierraCast® 94-6151-13 or similar toggle
- 12" small cable chain
- 5" 20g wire
- 2 small jump rings

Instructions

- Step 1: Cut the chain into two equal pieces. Cut two, 1" pieces of wire. Set aside.
- Step 2: Using a 1" piece of wire, create a simple loop and slide on (1) 8x5.5mm 5514 and close wire with a simple loop. Repeat once. Set aside.
- Step 3: Using the remaining wire, create a simple loop and slide on 1) 8x5.5mm 5514, (1) 10x7mm 5514, (1) 8x5.5mm 5514, (1) 10x7mm 5514 and (1) 8x5.5mm 5514, (1) 10x7mm 5514, (1) 8x5.5mm 5514. While holding the beads against the loop made, gently curve the wire. Close the wire with a simple loop.
- Step 4: Attach one bead component made in step 2 to each side of the component made in step 3.
- Step 5: Attach one piece of chain to each of the bead components added on in step 4.
- Step 6: Attach one jump ring and one half of the toggle clasp to one of the chain ends. Repeat for the opposite side.

A Splash of Raindrops Necklace – continued

Note: if you do not clean off the clay prior to it curing, the crystals will not be sparkling. Set aside on waxed paper to cure for a minimum of two hours before handling.

- Step 5: Attach two large jump rings to the leather strap tip hole. Set the pendant aside.
- Step 6: Fold over one end of the leather about $\frac{3}{4}$ " and while holding the created loop, slide on one 4x3 deco barrel. Using a nylon jaw plier, gently flatten the deco barrel only enough to keep it from moving out of place.
- Step 7: Slide the pendant and one deco barrel onto the leather piece from step 6 with the deco barrel at the open end of the leather. Fold over one end of the leather about $\frac{3}{4}$ " and slip on the twisted hook. While holding the created loop in place (using a nylon jaw plier) gently flatten the deco barrel only enough to keep it from moving out of place.
- Step 8: Cut the wire in two equal pieces. Wrap the wire onto the leather to one side of the pendant (which should be in the center of the leather strap) about three times. Slip on 24 5328 3mm crystals and continue to wrap around the leather (away from the pendant) keeping the beads as close together as you can so as not to have gaps. When you run out of crystals, wrap the remaining wire around the leather about 3 times. Repeat for the opposite side.

A Splash of Raindrops Ring



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Rain Drop Fancy stone	4331	3	20mm	Crystal Silver Shade	001 SSHA
Rain Drop Fancy stone	4331	4	15mm	Crystal Silver Shade	001 SSHA
Rain Drop Fancy stone	4331	17	11mm	Crystal Silver Night	001 SINI
Flat back	2088/G	1	SS34	Crystal Frosted	001
Ceralun® Epoxy	9030/296	1		Silver	

Supplies:

- 1 Ring form
- Cotton Swab
- Acetone
- Floral foam

Instructions

- Step 1: Prepare Ceralun as per package instructions. Mold clay onto ring form.
- Step 2: Embed the flat back into the clay on the center.
- Step 3: Using the pointed end of the Raindrop fancy stone, embed the stones as desired around the clay.
- Step 4: Clean off all clay smudges on the crystals with a cotton swab and acetone. Note: if you do not clean off the clay prior to it curing, the crystals will not be sparkling. Embed the ring form into floral foam and set aside to cure for a minimum of two hours before handling.

Mono-Chromed Earrings



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Sew-on stone	3188	24	5mm	Crystal Light Chrome	001 LTCH
Kaputt Pendant	6913	2	28mm	Crystal Light Chrome	001 LTCH
Bead	5328	12	3mm	Crystal Light Chrome	001 LTCH

Supplies:

1 pair 'add a bead' ear wire
2 9x6mm embossed brass cable chain links
5" 20g wire

Instructions

- Step 1: Attach one 9x6mm embossed link to the pendant. Repeat for second pair.
- Step 2: Cut the wire into two equal pieces. Using one piece create a simple loop, then slide onto the wire (1) 3mm 5328 bicone, (2) 5mm 3188 sew on stones (making sure they are back to back), repeat this pattern four more times and end with (1) 3mm 5328 bicone and end the wire with a simple loop. Repeat for the second pair.
- Step 3: Attach one end of the component made in step 2 to the component made in step 1. Repeat for the second pair.
- Step 4: Attach one ear wire to the simple loop remaining. Repeat for the second pair.

CREATE
YOUR STYLE

SWAROVSKI

Mono-Chromed Necklace



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328	24	6mm	Crystal Light Chrome	001 LTCH
Beads	5328	36	3mm	Crystal Light Chrome	001 LTCH
Beads	5040	12	8mm	Crystal Light Chrome	001 LTCH
Beads	5040	12	6mm	Crystal Light Chrome	001 LTCH
Beads	5601	12	6mm	Crystal Light Chrome	001 LTCH
Sew on stone	3188	~80	3mm	Crystal Light Chrome	001 LTCH
Sew on stone	3188	~80	5mm	Crystal Light Chrome	001 LTCH
Kaputt Pendant	6913	1	38mm	Crystal Light Chrome	001 LTCH

Supplies:

20" .014 beading wire

2 crimp beads

1 Heirloom toggle clasp TierraCast® 94-6070-13 or similar clasp

1 9x6mm embossed cable chain link

10 8x5mm brass cable links

~15 feet Pearl Cotton thread

Mono-Chromed Necklace - continued

Instructions

- Step 1: Crimp on half of the toggle onto the beading wire. Slip on (1) 6mm 5328, (1) 8mm 5040, (1) 3mm 5328, (1) 6mm 5601, (1) 3mm 5328, (1) 6mm 5040, (1) 3mm 5328; repeat this pattern 5 more times. Set aside.
- Step 2: Attach (1) 9x6mm embossed cable chain link to the Gautier Spiky pendant hole. Attach the 10 8x5mm brass chain links to the embossed 9x6mm chain link. Set aside.
- Step 3: Cut the pearl cotton into 10 15" pieces.
- Step 4: Using one 15" piece of pearl cotton; fold in half and tie an overhand knot about 8mm from the fold. Using one side of the thread, knot on (back to back) sets of 3188 3mm and 5mm sew on stones. Each thread should have 3-4 sets on it. Knot each set on as desired for placement. Repeat this step 9 times more. Set fringe aside.
- Step 5: Using the necklace component from step 1, slide on (1) 6mm 5328 bicone and (1) thread fringe from step 4 (you are slipping the beading wire into the loop at the top of the thread). Repeat this step 4 more times. Then add (1) 6mm 5328 bicone, the component made in step 2. Then slide on (1) 6mm 5328 bicone and (1) thread fringe from step 4 (you are slipping the beading wire into the loop at the top of the thread). Repeat this step 4 more times. Next, string on (1) 6mm 5328, (1) 3mm 5328, (1) 6mm 5040, (1) 3mm 5328, (1) 6mm 5601, (1) 3mm 5328 and (1) 8mm 5040. Repeat five times more. Lastly, add (1) 6mm 5328.
- Step 6: Crimp on the second half of the toggle closure.

CREATE
YOUR STYLE

SWAROVSKI

Garden of Scarabaeus Flowers - cell phone case



Materials

Swarovski crystals:

Product Group	Article No.	Amount	Size	Color	Color Code
Flatbacks	2088	40	Ss20	Crystal Scarabaeus Green	001 SCGR
Flatbacks	2088	4	Ss34	Crystal Scarabaeus Green	001 SCGR

Supplies:

1 cell phone cover

Gem Tac Glue

Crystal Katana or similar wax stick

2 Leather small Flower TierraCast® 21-0050-21 or similar leather flowers

1 Leather medium Flower TierraCast® 21-0051-21 or similar leather flower

1 Leather large Flower TierraCast® 21-0052-21 or similar leather flower

Instructions

Step 1: First lay out your design on the back of the cover.

Step 2: Dot the Gem Tac glue around the areas you are placing the leather flowers. Let the glue stand for about 1 minute to get tacky. Place flowers down on cover.

Step 3: Continue to dot glue on top of leather flowers and on the case in a pattern you like. Let stand for about 1 minute to get tacky. Using the Crystal Katana pick up and place crystals down one at a time on the cover. Let stand for 24 hours to fully dry.

CREATE
YOUR STYLE

SWAROVSKI

Cross Culture Necklace - (Inspirational Only)



Materials

Swarovski crystals

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5000	~40	2mm	Crystal Golden Shadow	001 GSHA
Sew-on Stone	3200	1	12mm	Crystal Golden Shadow	001 GSHA
Kaputt Fancy Stone	4925	1	29x11.5	Crystal Golden Shadow	001 GSHA
Pendants	6680	1	14mm	Crystal Golden Shadow	001 GSHA

Supplies:

15/0 Seed beads

Fire Line

18" small chain

Lobster clasp

4 4mm jump rings